



Peregrine Additives & Lubricants
(318) 222-8787
61318 Union Ave
Shreveport, La 71106

PAL PIPE GLIDE

INDUSTRY LEADING PIPE ON PIPE

PAL Pipe Glide is a new “Pipe on Pipe” lubricant designed especially for coil tubing and stick pipe jobs. It has been formulated to meet the high demands of even the most difficult wells and allow the operators to achieve total depth.

Pipe Glide is easily dispersed in any fluid condition from fresh water to fully saturated brines and provides a coefficient of friction well below the industry standard of 0.1, depending on fluid types, a coefficient as low as 0.05 can be easily achieved. Pipe Glide has a lasting effect as it has a high affinity for metal surfaces. Pipe Glide can be dosed as a continuous “drip” or on an as needed basis. For continuous applications, 1/8 to ¼ gallons per bbl is recommended. For on demand applications ½

to 1 gallon per 10bbls is normally used. When encountering severe friction issues Pipe Glide can be dosed as a pill in much higher concentrations. In the event of high friction, it is always recommended to run a high viscosity sweep to ensure the hole is clean and free of sand before high dosages of pipe on pipe is sent downhole.

Features

- **Dispersible and fully functional in all fluid conditions**
- **Withstands high bottom hole temps in excess of 176°C/350°F**
- **Compatible with all other chemistries used in workover and completion**
- **Pipe Glide is a clear, dark brown liquid with a strong sulphurous odor**
- **Pipe Glide is shipped in 5 gallon pails, 55 gallon drums, 275 gallon one way totes or bulk transport**